

Maintenance Tables - Severe Service

5,000-25,000 [30,000-50,000](#) [55,000-75,000](#) [80,000-100,000](#) [105,000-120,000](#)

Maintenance Items	5,000	10,000	15,000	20,000	25,000
Air Filter Element	Inspect	Inspect	Inspect	Inspect	Inspect
Automatic Transmission Fluid			Replace		
Ball Joint Dust Cover, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint Dust Cover, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Body and Frame	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Drum	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Hose			Inspect		
Brake Line			Inspect		
Brake Pad	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Rotor/Disc	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Shoe	Inspect	Inspect	Inspect	Inspect	Inspect
Brakes	Check	Check	Check	Check	Check
Constant Velocity Joint Boot	Inspect	Inspect	Inspect	Inspect	Inspect
Coolant					
Differential Fluid			Replace		
Drive Belt					
Drive/Propeller Shaft	Inspect	Inspect	Inspect	Inspect	Inspect
Evaporative Emission Control Canister					
Exhaust System			Inspect		
Fuel Delivery and Air Induction					
Fuel Filler Cap					
Fuel Supply Line					
Manual Transmission Fluid					
Oil	Replace	Replace	Replace	Replace	Replace
Oil Filter, Engine	Replace	Replace	Replace	Replace	Replace
Spark Plug					
Steering	Inspect	Inspect	Inspect	Inspect	Inspect
Steering and Suspension	Inspect	Inspect	Inspect	Inspect	Inspect
Tires	Rotate	Rotate	Rotate	Rotate	Rotate
Valve Clearance					

[5,000-25,000](#) [30,000-50,000](#) [55,000-75,000](#) [80,000-100,000](#) [105,000-120,000](#)

Maintenance Items	30,000	35,000	40,000	45,000	50,000
Air Filter Element	Replace	Inspect	Inspect	Inspect	Inspect
Automatic Transmission Fluid	Replace			Replace	
Ball Joint Dust Cover, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint Dust Cover, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Body and Frame	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Drum	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Hose	Inspect			Inspect	
Brake Line	Inspect			Inspect	
Brake Pad	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Rotor/Disc	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Shoe	Inspect	Inspect	Inspect	Inspect	Inspect
Brakes	Check	Check	Check	Check	Check
Constant Velocity Joint Boot	Inspect	Inspect	Inspect	Inspect	Inspect

Coolant	Replace				
Differential Fluid	Replace			Replace	
Drive Belt	Inspect				
Drive/Propeller Shaft	Inspect	Inspect	Inspect	Inspect	Inspect
Evaporative Emission Control Canister					
Exhaust System	Inspect			Inspect	
Fuel Delivery and Air Induction	Inspect				
Fuel Filler Cap	Reseal				
Fuel Supply Line	Inspect				
Manual Transmission Fluid	Replace				
Oil	Replace	Replace	Replace	Replace	Replace
Oil Filter, Engine	Replace	Replace	Replace	Replace	Replace
Spark Plug					
Steering	Inspect	Inspect	Inspect	Inspect	Inspect
Steering and Suspension	Inspect	Inspect	Inspect	Inspect	Inspect
Tires	Rotate	Rotate	Rotate	Rotate	Rotate
Valve Clearance					

5,000-25,000 30,000-50,000 55,000-75,000 80,000-100,000 105,000-120,000

Maintenance Items	<u>55,000</u>	<u>60,000</u>	<u>65,000</u>	<u>70,000</u>	<u>75,000</u>
Air Filter Element	Inspect	Replace	Inspect	Inspect	Inspect
Automatic Transmission Fluid		Replace			Replace
Ball Joint Dust Cover, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint Dust Cover, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Body and Frame	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Drum	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Hose		Inspect			Inspect
Brake Line		Inspect			Inspect
Brake Pad	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Rotor/Disc	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Shoe	Inspect	Inspect	Inspect	Inspect	Inspect
Brakes	Check	Check	Check	Check	Check
Constant Velocity Joint Boot	Inspect	Inspect	Inspect	Inspect	Inspect
Coolant		Replace			
Differential Fluid		Replace			Replace
Drive Belt		Inspect			Inspect
Drive/Propeller Shaft	Inspect	Inspect	Inspect	Inspect	Inspect
Evaporative Emission Control Canister		Inspect			
Exhaust System		Inspect			Inspect
Fuel Delivery and Air Induction		Inspect			
Fuel Filler Cap		Reseal			
Fuel Supply Line		Inspect			
Manual Transmission Fluid		Replace			
Oil	Replace	Replace	Replace	Replace	Replace
Oil Filter, Engine	Replace	Replace	Replace	Replace	Replace
Spark Plug		Replace			
Steering	Inspect	Inspect	Inspect	Inspect	Inspect
Steering and Suspension	Inspect	Inspect	Inspect	Inspect	Inspect
Tires	Rotate	Rotate	Rotate	Rotate	Rotate
Valve Clearance		Inspect			

[5,000-25,000](#) [30,000-50,000](#) [55,000-75,000](#) [80,000-100,000](#) [105,000-120,000](#)

Maintenance Items	80,000	85,000	90,000	95,000	100,000
Air Filter Element	Inspect	Inspect	Replace	Inspect	Inspect
Automatic Transmission Fluid			Replace		
Ball Joint Dust Cover, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint Dust Cover, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Lower	Inspect	Inspect	Inspect	Inspect	Inspect
Ball Joint, Upper	Inspect	Inspect	Inspect	Inspect	Inspect
Body and Frame	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Drum	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Hose			Inspect		
Brake Line			Inspect		
Brake Pad	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Rotor/Disc	Inspect	Inspect	Inspect	Inspect	Inspect
Brake Shoe	Inspect	Inspect	Inspect	Inspect	Inspect
Brakes	Check	Check	Check	Check	Check
Constant Velocity Joint Boot	Inspect	Inspect	Inspect	Inspect	Inspect
Coolant			Replace		
Differential Fluid			Replace		
Drive Belt			Inspect		
Drive/Propeller Shaft	Inspect	Inspect	Inspect	Inspect	Inspect
Evaporative Emission Control Canister					
Exhaust System			Inspect		
Fuel Delivery and Air Induction			Inspect		
Fuel Filler Cap			Reseal		
Fuel Supply Line			Inspect		
Manual Transmission Fluid			Replace		
Oil	Replace	Replace	Replace	Replace	Replace
Oil Filter, Engine	Replace	Replace	Replace	Replace	Replace
Spark Plug					
Steering	Inspect	Inspect	Inspect	Inspect	Inspect
Steering and Suspension	Inspect	Inspect	Inspect	Inspect	Inspect
Tires	Rotate	Rotate	Rotate	Rotate	Rotate
Valve Clearance					

[5,000-25,000](#) [30,000-50,000](#) [55,000-75,000](#) [80,000-100,000](#) [105,000-120,000](#)

Maintenance Items	105,000	110,000	115,000	120,000
Air Filter Element	Inspect	Inspect	Inspect	Replace
Automatic Transmission Fluid	Replace			Replace
Ball Joint Dust Cover, Lower	Inspect	Inspect	Inspect	Inspect
Ball Joint Dust Cover, Upper	Inspect	Inspect	Inspect	Inspect
Ball Joint, Lower	Inspect	Inspect	Inspect	Inspect
Ball Joint, Upper	Inspect	Inspect	Inspect	Inspect
Body and Frame	Inspect	Inspect	Inspect	Inspect
Brake Drum	Inspect	Inspect	Inspect	Inspect
Brake Hose	Inspect			Inspect
Brake Line	Inspect			Inspect
Brake Pad	Inspect	Inspect	Inspect	Inspect
Brake Rotor/Disc	Inspect	Inspect	Inspect	Inspect
Brake Shoe	Inspect	Inspect	Inspect	Inspect
Brakes	Check	Check	Check	Check
Constant Velocity Joint Boot	Inspect	Inspect	Inspect	Inspect
Coolant				Replace
Differential Fluid	Replace			Replace
Drive Belt	Inspect			Inspect

Drive/Propeller Shaft	Inspect	Inspect	Inspect	Inspect
Evaporative Emission Control Canister				Inspect
Exhaust System	Inspect			Inspect
Fuel Delivery and Air Induction				Inspect
Fuel Filler Cap				Reseal
Fuel Supply Line				Inspect
Manual Transmission Fluid				Replace
Oil	Replace	Replace	Replace	Replace
Oil Filter, Engine	Replace	Replace	Replace	Replace
Spark Plug				Replace
Steering	Inspect	Inspect	Inspect	Inspect
Steering and Suspension	Inspect	Inspect	Inspect	Inspect
Tires	Rotate	Rotate	Rotate	Rotate
Valve Clearance				Inspect